

Exhaust Servo Eliminator Supplementary Manual



Honda CRF1100 DCT Africa Twin 2020- (ESE-H05)

Locate the Exhaust Servo-motor at the back of the bike, near the rear suspension.



Remove the Exhaust Servo-motor.

Plug the ESE connectors to the Exhaust Servo-motor connectors.



Typical position for the Exhaust Servo Eliminator.

Secure the unit properly.

